

Conversion Instructions

PGi

- 1.** Convert CASE to tote by pressing top handle release button



- 2.** Pull handle upward until fully extended for TOTE



- 3.** Release tote position by lifting up button on underside of second handle to convert to CART



- 4.** Continue by pulling back handle and laying case flat on floor as shown in step 5



- 5.** Push down and pull back on handle until it moves past the right angle



- 6.** Handle will automatically clip and secure itself onto metal clasp as shown



- 7.** Once secured make sure handle is fully extended to complete the CART position



- 8.** To convert Cart back to TOTE, lower top of handle, then pull up on up on metal clasp and releasing handle



- 9.** Fold handle down by slowly lifting and pulling it towards the top of case



- 10.** IMPORTANT: Make sure holes at bottom of handle line up with pegs at bottom of case as you secure handle to back of case



- 11.** When the handle snaps in place it is in the stowed or carryon position

